



ICYNENE™

6747 Campobello Road
Mississauga, Ontario
Canada L5N 2L7
Toll Free: 800.758.7325
Telephone: 905.363.4040
Facsimile: 905.363.0102
Website: www.icynene.com

Insulation Fact Sheet

This is a spray-in-place foam insulation.

READ THIS BEFORE YOU BUY.
WHAT YOU SHOULD KNOW ABOUT R-VALUES.

R-Value, A.S.T.M. C-518, F. ft². hr. / Btu.

R-3.7 per inch
R-13 based on 3 1/2'
R-20 based on 5 1/2'

The chart shows R-value of this insulation.

R means resistance to heat flow. The higher the R-value, the greater the insulation power. Compare insulation R-values before you buy.

There are other factors to consider. The amount of insulation you need depends on the climate you live in. Also your fuel savings from insulation will depend upon the climate, the type and size of your house, the amount of insulation already in your house, and your fuel use patterns and family size. If you buy too much insulation, it will cost more than you'll save on fuel.

To get the market R-value, it is essential that this insulation be installed properly.



ICYNENE™

HEALTHIER, QUIETER, MORE ENERGY EFFICIENT*